

Included hardware:

Ten 6-32 x 1/2" F-type self tapping screws

Six 10-32 x 1/4" machine screws

- 1) Secure the light mounting panel to the back of the stock bezel using four 6-32 x 1/2" f-type self-tapping screws.
- 2) Install the three lights into the three openings in the light mounting panel. Secure the lights using the six 10-32 x 1/4" machine screws.
- 3) Secure the two aluminum gauge panels to the stock bezel using six 6-32 x 1/2" f-type self-tapping screws.
- 4) Install your gauges into the aluminum gauge panels & secure using the hardware provided by the gauge manufacturer.
- 5) Wire the gauges (refer to instructions provided by gauge manufacturer).

